

Usage in low and strong winds

LWS systems GmbH & Co. KG • Dorfstrasse 1a • D-23923 Lockwisch • Phone +49 38828 23140 • www.lws-systems.com

Recommended options:

WG100, strong wind:



WG100, low wind:



WG300, strong wind:



WG300, low wind:



WG500, strong wind:



WG500, low wind:



Für Generatoren anderer Hersteller gilt/Applies to generators of other manufacturers:

Wichtig: Der Anlaufmoment der Generatoren sollte unbedingt 0,03 N/m betragen.

Important: The starting torque of the generators should always be 0,03 N/m.